

PLASMA SPRAY PROCESSORS

Works Instruction

QF/QMS/02/32

Rev. 00

Date : 18/09/2023



Operations/Work/Job Activity covered by this assessment: Grinding Machine

Required Personal Protective Equipment (PPE) :



Safety glasses must be worn at times.



Long and loose hair must be contained.



Appropriate footwear with substantial uppers must be worn.



Close fitting/protective clothing to cover arms and legs must be worn.



Respiratory protection devices required.



Oil free leather gloves and spats must be worn.



Hearing protection must be used when using this machine.

1. After releasing the mounted specimen from Bain-Mount machine, clean the same with soap solution and the with running water.
2. Dry the specimen with good quality filter paper
3. With suitable engraver, put the specimen details on the backside of the mount so that it is parallel to the length of the specimen mounted.
4. Open the front cover and ensure that the Emery paper with Grit 80 is held firmly between the two rollers in the equipment
5. Close the front cover and switch ON the grinding machine.
6. Wear the proper fitting gloves on your hand.
7. When the emery starts rotating, hold the specimen as shown and start pressing against the rolling emery paper.
8. After few seconds viz., 20-30 secs, immerse the specimen in cold water or coolant kept in a beaker nearby and then remove the water on the specimen by drying with filter paper.
9. Repeat the process detailed in S.No.
10. The grinding process is over once the grinding lines are parallel and uniform over the entire length of the specimen



Assessor	Prasanna Wadkar	Signature:		Date:	
Approved:	Haarsh Doshi	Signature:		Date:	